


USB Wireless Adapter Quick Installation Guide

Note: This Manual based on Windows7



01. Put in the CD and find windows file "windows (xp,vista,win7,win8,win10)" and Setup.exe.



02. Double click Setup.exe file, Software begin to initialization, then click the "Next". There shows the installation progress.




03. Do not interrupt installation, Click "finish" to finish the driver installation. The computer automatically restart.





04. Plug the Wireless USB Adapter into the USB port of your PC

Wireless connection (two ways to realize Wireless connection 1 :

05. Click Icon  in the Windows system tray, which locates in the bottom-right corner of your computer screen or double click , and pops up a message and click "Available Network". Double-click the utility icon or right click the icon ,and the Wireless Network Connection window appears then double click the SSID you preferred.



Type the encryption key that you wrote down earlier in both the Network key and Confirm network key boxes, and then click "ok".



Note:if there is no icon , please find it in the on right bottom,it have been hide as following



pictures shows: Wireless Connection2.



Type the encryption key and then click "ok".



USB無線ランカード (REALTEK) ドライブインストール・ガイド

説明: 本インストール・ガイドはWin7システムの環境のインストールを選択し、他のWindowsシステムは参考として利用される。

ドライバのインストール:

1. 光学ドライブを開き、光ディスクをいれ、 Setup.exeのインストール・ファイルをダブルクリックして実行させる。



2. ドライブ・プログラムはインストールを準備する。



3. 「下一步」をクリックしてインストールを続ける





04. 無線ランカードをパソコンのUSBポートに挿入する
LANカード使用:
ネットワーク接続方:

1. デスクトップアイコン  をダブルクリックし、或いはタスクバーの右下のアイコン  をクリックし、無線ネットワークの接続ダイアログボックスを開きます。「可用网络」(利用可能なネットワーク) タブをクリックし、「刷新」(リフレッシュ) ボタンをクリックし、接続の必要な無線ネットワーク信号をダブルクリックします。



LANカード使用:
ネットワーク接続方:



Note:if there is no icon , please find it in the on right bottom,it have been hide as following




pictures shows: Wireless Connection2.

1. タスクバーの右下のアイコン  をクリックし、無線ネットワーク・リストを開きます。接続の必要な無線ネットワーク信号をダブルクリックし、或いは「接続」ボタンをクリックします。ダイアログボックスに無線ネットワークの接続パスワードを入力し、「確定」ボタンをクリックしてインターネットが利用できます。



Type the encryption key and then click "ok".



親切なご注意: 例示のピクチャによる無線ネットワークリストは、ユーザーの使用環境によって異なります。