

Quality Warranty Card

After-sales service

If there is an issue with your clock, remote or power cord, any problems you can contact us through Amazon message.

Any Problem, Please send Amazon message to seller.

3D LED Wall Clock

User manual

English manual

Deutsches Handbuch

日本語マニュアル

Please read the instruction manual carefully before using the product, and save this instruction manual as a reference for future use.

Due to product upgrade or other reasons, this manual will be updated regularly. The company reserves the right to change the content without notice.

Product overview and main features

SET / Pairing

Hook hole

Power interface

Detachable base

Download APP

1. Search and download "Tuya Smart" on the App Store or Google Play

2. Scan the QR code below to download.

Google play

App Store

Software registration and login

1. Register:

If you don't already have an app account, you can create an account or log in with an existing account.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

2.Existing account login:

If you already have an app account, you can log in with your account or password.

1. The system automatically selects the current country/language, or you can manually select the country/language.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

Connect the EDUP Clock to the mobile device

1. Important: The EDUP Clock only supports 2.4GHz Wi-Fi.

2. In order to establish the network connection, please make sure that the EDUP Clock and mobile device are close to each other.

3. Option 1: Automatic Connection

IMPORTANT:

1. Turn on the Bluetooth of your phone.

2. Power on your EDUP Clock, and long press Pairing key five seconds.

3. Select 2.4G Wi-Fi Network of your phone.

Features

1. Click the QR Code on the "Tuya Smart" main interface to enter the EDUP Clock interface, and you can operate and control the Clock on the interface.

2. When the alarm goes off, you can operate and control the Clock on the interface.

3. When the alarm goes off, you can operate and control the Clock on the interface.

4. When the alarm goes off, you can operate and control the Clock on the interface.

5. When the alarm goes off, you can operate and control the Clock on the interface.

Attention

1. Product inspections were strictly made before outbound.

2. Fixing hooks are included in case your house have made or all walls that cannot be driven nails in (applicable to smooth walls without pattern).

3. Make sure the LED wall clock works properly first if you want to embed power cord in wall.

(* It's forbidden to use 220V power supply directly after cutting cab cable)

Instruction Manual

Thanks for choosing the 3D LED Wall Clock product. Please read the Instruction Manual carefully before using the product.

Product composition and accessories

Remote control

USB cable

Wireless remote control

Matters needing attention related to the power supply

The power line and the terminal port of the wall clock cannot be separated after connection.

The USB cable should not be over-bent. Do not pull the wire hard when it is bent.

If the wire is broken due to over-bent, the repair should be made.

Do not connect the wall clock directly to the 220V power supply in length or in width of the power plug or wall.

When using the power cord, please pay attention to avoiding contact with water or moisture in order to avoid electric shock.

Do not touch the wall clock with wet hands. Pay attention to avoiding contact with water or moisture in order to avoid electric shock.

Do not use the wall clock near flammable materials, direct rays of the sun or extreme cold.

Do not use the wall clock near flammable materials, direct rays of the sun or extreme cold.

Do not use the wall clock near flammable materials, direct rays of the sun or extreme cold.

Do not use the wall clock near flammable materials, direct rays of the sun or extreme cold.

Installation methods of the wall clock

1. Register:

Place the clock on the back of the terminal port on the back of the product.

2. Fixing hole:

Place the fixing hole of the screen behind the wall clock on the head screen.

3. Power interface:

Place the power interface of the screen behind the wall clock on the head screen.

Function set of the remote control

Power button: Cancel the set values

Function setting: Set the function

1224-hour display mode: Set the 1224-hour display mode

Colon flashing: Press 4 times

Loop display: Press 4 times

Color setting: Press 4 times

Usage

Power button: Press the "Power" button to enter the power button setting mode.

Function setting: Press the "Function" button to enter the function setting mode.

1224-hour display mode: Press the "1224" button to enter the 1224-hour display mode.

Colon flashing: Press the "Colon" button to enter the colon flashing mode.

Loop display: Press the "Loop" button to enter the loop display mode.

Color setting: Press the "Color" button to enter the color setting mode.

Usage

Date setting button: Press the "Date" button to enter the date setting mode.

Alarm setting: Press the "Alarm" button to enter the alarm setting mode.

Turn Alarm ON/OFF: Press the "Alarm" button to enter the alarm setting mode.

Temperature Adjustment: Press the "Temp" button to enter the temperature setting mode.

Count Up: Press the "Count Up" button to enter the count up mode.

Count Down: Press the "Count Down" button to enter the count down mode.

Usage

Turn Alarm ON/OFF: Press the "Alarm" button to enter the alarm setting mode.

Temperature Adjustment: Press the "Temp" button to enter the temperature setting mode.

Count Up: Press the "Count Up" button to enter the count up mode.

Count Down: Press the "Count Down" button to enter the count down mode.

3D LED Wanduhr

Benutzerhandbuch

SET / Pairing

Hook hole

Power interface

Detachable base

App herunterladen

1. Suchen und laden Sie "Tuya Smart" in der App Store oder bei Google Play herunter.

2. Scannen Sie den untenstehenden QR-Code zum Download.

Google play

App Store

Software-Registrierung und Anmeldung

1. Registrieren:

If you don't already have an app account, you can create an account or log in with an existing account.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

Verbindung des EDUP Clock mit dem Mobilgerät

1. Wichtig: Dieser EDUP Clock unterstützt nur 2,4 GHz Wi-Fi.

2. Um die Netzwerkverbindung zu stabilisieren, stellen Sie sicher, dass der EDUP Clock und das Mobilgerät in der Nähe des Routers sind.

3. Option 1: Automatische Verbindung.

Wichtiger Hinweis:

1. Schneiden Sie das Netzkabel nicht ab.

2. Schneiden Sie das Netzkabel nicht ab.

3. Schneiden Sie das Netzkabel nicht ab.

App herunterladen

1. Suchen und laden Sie "Tuya Smart" in der App Store oder bei Google Play herunter.

2. Scannen Sie den untenstehenden QR-Code zum Download.

Google play

App Store

Software-Registrierung und Anmeldung

1. Registrieren:

If you don't already have an app account, you can create an account or log in with an existing account.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

Verbindung des EDUP Clock mit dem Mobilgerät

1. Wichtig: Dieser EDUP Clock unterstützt nur 2,4 GHz Wi-Fi.

2. Um die Netzwerkverbindung zu stabilisieren, stellen Sie sicher, dass der EDUP Clock und das Mobilgerät in der Nähe des Routers sind.

3. Option 1: Automatische Verbindung.

Wichtiger Hinweis:

1. Schneiden Sie das Netzkabel nicht ab.

2. Schneiden Sie das Netzkabel nicht ab.

3. Schneiden Sie das Netzkabel nicht ab.

Eigenschaften

1. Click the QR Code on the "Tuya Smart" main interface to enter the EDUP Clock interface, and you can operate and control the Clock on the interface.

2. When the alarm goes off, you can operate and control the Clock on the interface.

3. When the alarm goes off, you can operate and control the Clock on the interface.

4. When the alarm goes off, you can operate and control the Clock on the interface.

5. When the alarm goes off, you can operate and control the Clock on the interface.

Verwendung

Ein/Ausschalten: Click the "Power" button to enter the power button setting mode.

Helgelichtsteuerung: Click the "Light" button to enter the light setting mode.

Zeiteinstellung: Click the "Time" button to enter the time setting mode.

Achtung

1. Produktinspektionen wurden vor dem Versand streng durchgeführt.

2. Fixierungshaken sind enthalten, falls Ihr Haus Mauer- oder Kalkputz hat, in die keine Nagel eingeschlagen werden können (gilt für glatte Wände ohne Muster).

3. Stellen Sie sicher, dass die LED-Wanduhr ordnungsgemäß funktioniert, wenn Sie das Netzkabel in die Wand einbauen möchten.

(* Es ist verboten, das 220V-Netzteil direkt nach dem Abschneiden des USB-Kabels zu verwenden.)

Bedienungsanleitung

Viel Spaß bei der Verwendung dieses Produkts wünscht die Bedienungsanleitung und dankt Sie für die Kaufentscheidung.

Produktzusammensetzung und -bezeichnungen

Fernbedienung

USB-Kabel

Kabelabstreifen

Hinweise zur Stromversorgung

Das Netzkabel und die Anschlusskabel der Wanduhr können nach dem Anschließen nicht getrennt werden.

Das USB-Kabel sollte nicht übermäßig gebogen werden.

Wenn Sie das Kabel direkt hart zu ziehen, kann es beschädigt werden.

Wenn das Kabel gebogen wird, kann es beschädigt werden.

Wenn das Kabel gebogen wird, kann es beschädigt werden.

Wenn das Kabel gebogen wird, kann es beschädigt werden.

Einstellungsmodus der Wanduhr

20:00: Temperatur

03:02: Datum

01:00: Alarm

24:00: 24-Stunden-Modus

12:00: 12-Stunden-Modus

Installationsmethoden der Wanduhr

1. Register:

Place the clock on the back of the terminal port on the back of the product.

2. Fixing hole:

Place the fixing hole of the screen behind the wall clock on the head screen.

3. Power interface:

Place the power interface of the screen behind the wall clock on the head screen.

Funktionseinstellung der Fernbedienung

1. Register:

Place the clock on the back of the terminal port on the back of the product.

2. Fixing hole:

Place the fixing hole of the screen behind the wall clock on the head screen.

3. Power interface:

Place the power interface of the screen behind the wall clock on the head screen.

Verwendung

Ein/Ausschalten: Click the "Power" button to enter the power button setting mode.

Helgelichtsteuerung: Click the "Light" button to enter the light setting mode.

Zeiteinstellung: Click the "Time" button to enter the time setting mode.

Verwendung

Ein/Ausschalten: Click the "Power" button to enter the power button setting mode.

Helgelichtsteuerung: Click the "Light" button to enter the light setting mode.

Zeiteinstellung: Click the "Time" button to enter the time setting mode.

Verwendung

Ein/Ausschalten: Click the "Power" button to enter the power button setting mode.

Helgelichtsteuerung: Click the "Light" button to enter the light setting mode.

Zeiteinstellung: Click the "Time" button to enter the time setting mode.

Verwendung

Ein/Ausschalten: Click the "Power" button to enter the power button setting mode.

Helgelichtsteuerung: Click the "Light" button to enter the light setting mode.

Zeiteinstellung: Click the "Time" button to enter the time setting mode.

3D LEDウォールクロック

ユーザーマニュアル

SET / Pairing

Hook hole

Power interface

Detachable base

アプリをダウンロード

1. App Store / Google Playで "Tuya Smart" を検索してダウンロードしてください。

2. QRコードをスキャンしてダウンロードしてください。

Google play

App Store

ソフトウェアの登録とログイン

1. 登録:

If you don't already have an app account, you can create an account or log in with an existing account.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

重要なお知らせ:

1. スマートフォンの電源をオフにしないでください。

2. EDUP Clockの電源をオフにしないでください。

3. スマートフォンの電源をオフにしないでください。

アプリをダウンロード

1. App Store / Google Playで "Tuya Smart" を検索してダウンロードしてください。

2. QRコードをスキャンしてダウンロードしてください。

Google play

App Store

ソフトウェアの登録とログイン

1. 登録:

If you don't already have an app account, you can create an account or log in with an existing account.

2. Scan the QR code below to register.

3. Login:

If you already have an app account, you can log in with your account or password.

重要なお知らせ:

1. スマートフォンの電源をオフにしないでください。

2. EDUP Clockの電源をオフにしないでください。

3. スマートフォンの電源をオフにしないでください。

特徴

1. Click the QR Code on the "Tuya Smart" main interface to enter the EDUP Clock interface, and you can operate and control the Clock on the interface.

2. When the alarm goes off, you can operate and control the Clock on the interface.

3. When the alarm goes off, you can operate and control the Clock on the interface.

4. When the alarm goes off, you can operate and control the Clock on the interface.

5. When the alarm goes off, you can operate and control the Clock on the interface.

特徴

1. Click the QR Code on the "Tuya Smart" main interface to enter the EDUP Clock interface, and you can operate and control the Clock on the interface.

2. When the alarm goes off, you can operate and control the Clock on the interface.

3. When the alarm goes off, you can operate and control the Clock on the interface.

4. When the alarm goes off, you can operate and control the Clock on the interface.

5. When the alarm goes off, you can operate and control the Clock on the interface.

注意

1. 出荷前に製品検査を厳密に実施しました。

2. 家の壁がモルタルやアートの場合は、釘を打つことができません。ご了承ください。フックが付属していません (凹凸のない平らな壁に適用) 。

3. LED取り付け時が壁面に穴を開けることを確認し、上で、電源コードを壁面に穴を開けることを確認してください。

(* 220V電源は、USBケーブルを切断した直後に使用することはお断りされています。)

注意

1. 出荷前に製品検査を厳密に実施しました。

2. 家の壁がモルタルやアートの場合は、釘を打つことができません。ご了承ください。フックが付属していません (凹凸のない平らな壁に適用) 。

3. LED取り付け時が壁面に穴を開けることを確認し、上で、電源コードを壁面に穴を開けることを確認してください。

(* 220V電源は、USBケーブルを切断した直後に使用することはお断りされています。)

取扱説明書 (しゅとくきまいいしよ)

1. EDUPウォールクロックは、壁に取り付けることができます。

2. EDUPウォールクロックは、壁に取り付けることができます。

3. EDUPウォールクロックは、壁に取り付けることができます。

4. EDUPウォールクロックは、壁に取り付けることができます。

5. EDUPウォールクロックは、壁に取り付けることができます。

電源に関する注意事項

電源コードと電源ケーブルの接続は慎重に行ってください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

取付け時計の取り付け方法

1. 時計の裏面に電源ケーブルを接続してください。

2. 時計の裏面に電源ケーブルを接続してください。

3. 時計の裏面に電源ケーブルを接続してください。

4. 時計の裏面に電源ケーブルを接続してください。

5. 時計の裏面に電源ケーブルを接続してください。

リモコンの機能設定

1. リモコンの電源をオンにしてください。

2. リモコンの電源をオンにしてください。

3. リモコンの電源をオンにしてください。

4. リモコンの電源をオンにしてください。

5. リモコンの電源をオンにしてください。

取扱説明書 (しゅとくきまいいしよ)

1. EDUPウォールクロックは、壁に取り付けることができます。

2. EDUPウォールクロックは、壁に取り付けることができます。

3. EDUPウォールクロックは、壁に取り付けることができます。

4. EDUPウォールクロックは、壁に取り付けることができます。

5. EDUPウォールクロックは、壁に取り付けることができます。

電源に関する注意事項

電源コードと電源ケーブルの接続は慎重に行ってください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

電源コードは、壁に取り付ける前に、必ず電源コードを確認してください。

取付け時計の取り付け方法

1. 時計の裏面に電源ケーブルを接続してください。

2. 時計の裏面に電源ケーブルを接続してください。

3. 時計の裏面に電源ケーブルを接続してください。

4. 時計の裏面に電源ケーブルを接続してください。

5. 時計の裏面に電源ケーブルを接続してください。

リモコンの機能設定

1. リモコンの電源をオンにしてください。

2. リモコンの電源をオンにしてください。

3. リモコンの電源をオンにしてください。

4. リモコンの電源をオンにしてください。

5. リモコンの電源をオンにしてください。

使い方

電源ボタン: Click the "Power" button to enter the power button setting mode.

ヘルプボタン: Click the "Help" button to enter the help setting mode.

設定ボタン: Click the "Setting" button to enter the setting mode.

使い方

電源ボタン: Click the "Power" button to enter the power button setting mode.

ヘルプボタン: Click the "Help" button to enter the help setting mode.

設定ボタン: Click the "Setting" button to enter the setting mode.

使い方

電源ボタン: Click the "Power" button to enter the power button setting mode.

ヘルプボタン: Click the "Help" button to enter the help setting mode.

設定ボタン: Click the "Setting" button to enter the setting mode.

使い方

電源ボタン: Click the "Power" button to enter the power button setting mode.

ヘルプボタン: Click the "Help" button to enter the help setting mode.

設定ボタン: Click the "Setting" button to enter the setting mode.

小冊子
折后尺寸: 10x15 cm