

Quick Installation Guide

V1.0

Application schematic

Internet ADSL Router Switch

Wired access Wired access

PCIE network card PCIE network card

1. Hardware installation

1 2

2. Driver Installation (e.g. win 7)

a. The installation wizard will pop up automatically, click the installation program for your matching operating system.

2.5G Ethernet card installation wizard

Please select your system

Win7 Win8/8.1 Win10 Win11 other systems

! If the above interface does not pop up automatically, please turn on the computer and double-click to run the CD drive. Before installing the driver, please turn off the firewall or other security protection software to prevent false alarms or block the installation during the installation process.

b. Click "Next "

Realtek Ethernet Controller Driver - InstallShield Wizard

Welcome to use Realtek Ethernet Controller Driver InstallShield Wizard

InstallShield® Wizard will install Realtek Ethernet Controller Driver on your computer. To continue, click "Next".

Back Next Cancel

c. Click "Install" and wait for about 1 minute, then click "Finish" to end the installation.

Realtek Ethernet Controller Driver - InstallShield Wizard

The program can be installed. The wizard is ready and the installation can begin.

Click "Install" to begin the installation. If you want to check or change any installation settings, click "Back". Click "Cancel" to exit the installation wizard.

Back Install Cancel

Tips: Connect the network cable after the installation is complete, and you can access the Internet normally.

快速安装指南

V1.0

应用示意图

Internet ADSL 路由器 交换机

有线接入 有线接入

PCI-E网卡 PCI-E网卡

1.硬件安装

1 2

2、驱动安装（以win7为例）

a. 自动弹出安装向导，点击您所匹配的操作  
系统安装驱动

2.5G以太网卡安装向导

请选择您的系统：

Win7 Win8/8.1 Win10 Win11 其他系统

! 若以上界面没有自动弹出，请打开计算机，双击运行CD驱动器。安装驱动前请关闭防火墙或者其他安全防护软件，防止安装过程中误报或阻止安装。

b. 点击 “下一步”

Realtek Ethernet Controller Driver - InstallShield Wizard

欢迎来到 Realtek Ethernet Controller Driver InstallShield Wizard

InstallShield® Wizard 将安装 Realtek Ethernet Controller Driver 到您的计算机。要继续，请点击“下一步”。

Back 上一步 下一步 取消

c. 点击 “安装”，等待大约1分钟后, 点击  
“完成”，结束安装

Realtek Ethernet Controller Driver - InstallShield Wizard

可以安装该程序了  
您已准备好，可以开始安装了。

单击“安装”以开始安装。  
如果您要更改或取消任何安装设置，请单击“上一步”。单击“取消”退出安装向导。

Back 上一步 安装 取消

提示：完成安装后接入网线，可正常上网。

尺寸：375 x 85 mm （展开尺寸）

正反面印刷